

# Here+ Usage Instruction

1. connect your base to your laptop USB.
2. start mission planner
3. go to initial settings
4. look under optional accessories, for RTK / GPS Inject
5. select the Auto configure, and select the port your GPS is on.
6. start

at the plane or copter... connect the GPS as normal, and go fly!